

# How do I hook up ?

- You will need to carry:
  - 1/8" Mini jack
  - RCA plug
  - 1/4" Phono plug
- The Hilton Micro 100, AC-205, AC-500, MA150 & MA500 Use the Mini jack
- All the 75 models use the RCA plug
- Everything else uses the 1/4" Phono plug
- NEVER under any circumstances should you plug into the Microphone jack.

# CAUTION!

- The machines that use the RCA or 1/4" Phono plug disable the Tone Arm!
- Also, with these two plug types and a mini player you will require a volume booster.